


**KitchenAid®**

## CABINET PARTS

## REFRIGERATOR

For Models: KSRD22FKWH15, KSRD22FKBT15, KSRD22FKSS15, KSRD22FKBL15, KSRD22FKST15  
(White) (Biscuit) (Stainless Steel) (Black) (Stainless-VCM)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CABINET PARTS

For Models: KSRD22FKWH15, KSRD22FKBT15, KSRD22FKSS15, KSRD22FKBL15, KSRD22FKST15


(White) (Biscuit) (Stainless Steel) (Black) (Stainless-VCM)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Literature Parts	14	2217075	Hinge Bottom (2)	25	549193	Clamp, Service
	2305802	Use & Care Guide	15		Filler, Wrapper			Cord
2255384		Service & Wiring		2196094	White	26	489084	Screw
		Sheet		2196150	Biscuit	27	2155311	Door Closer,
2308419		Energy Guide		2196097	Black			Lower Cam (2)
628370		Modular Icemaker			Grille	28	489483	Screw
		Service Sheet	16	2186882W	White	29	2186443	Housing, Water
2	2174748	Front Roller (2)		2186882T	Biscuit			Filter
3	3400517	Screw		2186882B	Black	30	2255519	Water Filter
4	2196236	Roller (Rear) (2)	17	3400113	Screw	31	489500	Screw
5	489427	Screw	18	489464	Screw	32		Cap, Water Filter
6	2155013	Clip, Grille	19	940139	Drain Fitting	2186494W		White
7	488500	Screw	20	1108438	Extension Tube	2186494T		Biscuit
8		Cabinet (Not A	21	1108439	Clip, Drain Tube	2186494B		Black
		Serviceable Part)	22	8281227	Screw	33	3400103	Screw
9	2209697	Shim	23	2188736	Cover, Unit	34	2304249	Plate, Screw
10	2203770	Hinge Top, FC	24		Hinge Cover, RC	35	489497	Screw
11	2203771	Hinge Top, RC		2203408W	White	36	2255012	Tube, Filter
12	8281149	Screw		2203408T	Biscuit			Outlet
13		Hinge Cover, FC		2203408B	Black	37	2305536	Tube, Filter
	2203407W	White						Inlet
	2203407T	Biscuit						
	2203407B	Black						

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# REFRIGERATOR LINER PARTS

For Models: KSRD22FKWH15, KSRD22FKBT15, KSRD22FKSS15, KSRD22FKBL15, KSRD22FKST15  
 (White) (Biscuit) (Stainless Steel) (Black) (Stainless-VCM)




Illus.	Part No.	DESCRIPTION
1		Liner (Not A Serviceable Part)
2	2194744	Escutcheon, Meat Pan Control
3	2182757	Slide Meat Pan Control
4	2257741	Louver
5	2256035	Bracket, Dual Crisper Lights
8	2256037	Wire Harness, Dual Crisper Lights
10	2206270	Ladder, Shelf
11	486298	Screw (2)
16	2179404	Rack, Wire & Egg
22	2256085	Bracket Retainer
23	489290	Screw, (2)
24	2209753	Air Diffuser Assembly
25	2152019	Air Diffuser Cover
26	2150331	Cover, Conduit
27	489478	Screw
29	2162085	Socket
31	2256126	Reservoir
32	488280	Screw
33	527949	Light Bulb
34	2209769	Light Lens

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# REFRIGERATOR SHELF PARTS

For Models: KSRD22FKWH15, KSRD22FKBT15, KSRD22FKSS15, KSRD22FKBL15, KSRD22FKST15  
 (White) (Biscuit) (Stainless Steel) (Black) (Stainless-VCM)




Illus. No.	Part No.	DESCRIPTION
1	2179350	Deflector
2	2196485	Stud Assembly
3	2209698	Cover, Crisper
4	3400894	Screw
5	2196483	Stud Assembly
6	2216102	Spillguard, Slide Out (2)
7	2206097	Glass, Crisper Cover
8	2217039	Cover, Meat Pan
9	2195975	Frame, Shelf
10	8281158	Screw
12	2188652	Crisper Pan
13	2194913	Trim, Crisper
14	2179343	Housing, Humidity (Control)
15	2179259	Glass, Meat Cover
16	2179342	Slide, Humidity (Control)
17	2188654	Meat Pan
18	2206346	Shelf, Snack Bin
19	2188655	Snack Bin (Includes item 20)
20	2179243	Trim, Snack Bin
21	2194906	Trim, Meat Pan

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# FREEZER LINER PARTS

For Models: KSRD22FKWH15, KSRD22FKBT15, KSRD22FKSS15, KSRD22FKBL15, KSRD22FKST15  
(White) (Biscuit) (Stainless Steel) (Black) (Stainless-VCM)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# FREEZER LINER PARTS


For Models: KSRD22FKWH15, KSRD22FKBT15, KSRD22FKSS15, KSRD22FKBL15, KSRD22FKST15  
(White) (Biscuit) (Stainless Steel) (Black) (Stainless-VCM)

Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A Seviceable Part)
2	1115380	Slide, Ice Door
3	2171712	Door, Ice Compartment
4		Slide, Container
	1119293	Right Side
	1119237	Left Side
5	489478	Screw
6	842534	Clip, Air Duct (2)
7	2196206	Support, Stud
8	2174249	Shelf, Small (1)
9	940014	Plug, Hole
10	2176134	Grommet
11	2301193	Basket, Sloped
12	2196483	Stud Assembly
13	8281158	Screw
16	3400893	Screw
17		Slide, Freezer Bin
	2261449	Right Side
	2261448	Left Side
18	2196207	Stud, Rear
19	1115373	Switch, Rocker Arm
20	489100	Screw
21	2301192	Basket, Square
22	2171768	Front, Basket

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# MOTOR AND ICE CONTAINER PARTS

For Models: KSRD22FKWH15, KSRD22FKBT15, KSRD22FKSS15, KSRD22FKBL15, KSRD22FKST15



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# MOTOR AND ICE CONTAINER PARTS


For Models: KSRD22FKWH15, KSRD22FKBT15, KSRD22FKSS15, KSRD22FKBL15, KSRD22FKST15  
(White) (Biscuit) (Stainless Steel) (Black) (Stainless-VCM)

Illus. No.	Part No.	DESCRIPTION
1	2183728	Bracket, Motor
2	2188385	Motor, Dispenser
3	2152713	Soleniod Assembly
4	2149100	Guide, Solenoid
6	1115374	Clip, Wiring
7	2206501	Wiring Assembly, Ice Dispenser
8	489399	Screw
9	2205716	Coupling, Motor
10	489478	Screw
11	2162085	Socket, Light
14	2196089	Ice Container
18	1119005	Spacer, Step (3)
19	1119007	Spacer, Flat (2)
20	2257022	Blade, Rotary
21	2257023	Blade, Rotary
22	2257024	Blade, Rotary
23	489235	Washer, Plain
24	1119009	Blade, Fixed (2)
25	2157405	Block, Blade
26	489229	Roll Pin
27	2196295	Auger
28	2209781	Drum
30	2171682	Floating Baffle
31	1119018	Nut, Bearing
32	2155231	Control Arm
33	1119020	Spring, Return
34	1119021	Retainer Clip, Rod
35	488886	Screw
37	2180348	Housing, Crusher
38	1119017	Deflector, Ice
39	489234	Washer, Plain
40	489236	Retainer Ring
44	2171709	Front Cover, Ice Container
45	527949	Light Bulb
46	2171706	Light Lens, Dispenser

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# REFRIGERATOR DOOR PARTS

For Models: KSRD22FKWH15, KSRD22FKBT15, KSRD22FKSS15, KSRD22FKBL15, KSRD22FKST15  
(White) (Biscuit) (Stainless Steel) (Black) (Stainless-VCM)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# REFRIGERATOR DOOR PARTS


For Models: KSRD22FKWH15, KSRD22FKBT15, KSRD22FKSS15, KSRD22FKBL15, KSRD22FKST15  
 (White) (Biscuit) (Stainless Steel) (Black) (Stainless-VCM)

Illus. No.	Part No.	DESCRIPTION
1	2207330W	Refrigerator Door White
	2207330T	Biscuit
	2207330S	Stainless Steel
	2207330B	Black
	2207330L	Stainless-VCM (Includes Item #6)
2	2218122	Door, Compartment
3	2171063	Shelf Bin (4)
4	489491	Screw
6		Door, Gasket
	2221300	Mist Beige
	2221311	Black
		Magnetic
7		Insert, Handle
	2173830	White
	2200434	Biscuit
	2173832	Black
8		End Cap
	2194778W	White
	2194778T	Biscuit
	2194778B	Black
9	2159124	Gasket
10	2193409	Holder, Beverage
11	2182178	Door Closer, Upper Cam
12	489420	Screw
13		Bracket, Door Stop
	2206629	Bright Zinc
	2206629B	Black
14		Retainer, Insert
	2194776W	White
	2194776T	Biscuit
	2194776B	Black
16	2308091	Thimble-Top
17	3400852	Screw
22	3400012	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# FREEZER DOOR PARTS

For Models: KSRD22FKWH15, KSRD22FKBT15, KSRD22FKSS15, KSRD22FKBL15, KSRD22FKST15  
(White) (Biscuit) (Stainless Steel) (Black) (Stainless-VCM)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# FREEZER DOOR PARTS


For Models: KSRD22FKWH15, KSRD22FKBT15, KSRD22FKSS15, KSRD22FKBL15, KSRD22FKST15  
 (White) (Biscuit) (Stainless Steel) (Black) (Stainless-VCM)

Illus. No.	Part No.	DESCRIPTION
1	2216262W	Freezer Door White
	2216262T	Biscuit
	2216262S	Stainless Steel
	2216262B	Black
	2216262L	Stainless-VCM (Includes Item #6 And Dispenser Front Parts)
2	2173830	Insert, Handle White
	2200434	Biscuit
	2173832	Black
3	2194778W	End Cap White
	2194778T	Biscuit
	2194778B	Black
4	2194776W	Retainer, Insert White
	2194776T	Biscuit
	2194776B	Black
5	3400852	Screw
6		Door, Gasket Magnetic
	2221301	Mist Beige
	2221312	Black
7	2209680	Trim, Door Shelf
8	2209709	Connector, Dispenser Tube
9	8281149	Screw
11	2182179	Door Closer, Upper Cam
12	489420	Screw
13	2206629	Bracket, Door Stop
16	3400012	Screw
19	2171071	Shelf Bin (4)
20	489491	Screw
25	2187324	Wire Assembly
26	2154473	Connector
28	2182181	Thimble-Top

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# DISPENSER FRONT PARTS

For Models: KSRD22FKWH15, KSRD22FKBT15, KSRD22FKSS15, KSRD22FKBL15, KSRD22FKST15  
(White) (Biscuit) (Stainless Steel) (Black) (Stainless-VCM)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# DISPENSER FRONT PARTS


For Models: KSRD22FKWH15, KSRD22FKBT15, KSRD22FKSS15, KSRD22FKBL15, KSRD22FKST15  
 (White) (Biscuit) (Stainless Steel) (Black) (Stainless-VCM)

Illus. No.	Part No.	DESCRIPTION
1		Housing, Dispenser (Not Serviced)
2	3196537	Screw
3	2194719	Retainer, Levers
4	2256199	Spring, Torsion
5	2196195	Pin
6	2180353	Door, Ice
7	2304355	Door Mechanism Assembly
8	2205686	Mechanism Delay
9		Grille, Overflow
	2206671W	White
	2206671T	Biscuit
	2206671B	Black
10	2304317	Water Fitting Assembly (Includes Water Tube)
11		Lever, Ice Dispenser
	2180259	White
	2186850	Biscuit
	2180261	Black
12	2180224	Guide, Ice
13	2180200	Lamp Holder
14	2162361	Switch (4)
15	2183771	Bracket, Control
16	3406124	Bulb, Light
17		Lever, Water Dispenser
	2180268	White
	2186852	Biscuit
	2180270	Black
18		Switch Assembly (Not Available, Order #23)
19		Overlay, Front Cover (Not Available, Order #23)
20	2187409	Wire Assembly
21		Front Cover, Housing (Not Available, Order #23)
22	489000	Screw
23		Front Cover Assembly (Includes Items 18, 19, 20 & 21)
	2206801W	White
	2206801T	Biscuit
	2206801B	Black
24	2188355	Bracket, Dispenser
25	2195051	Strain Relief

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# UNIT PARTS

For Models: KSRD22FKWH15, KSRD22FKBT15, KSRD22FKSS15, KSRD22FKBL15, KSRD22FKST15  
 (White) (Biscuit) (Stainless Steel) (Black) (Stainless-VCM)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# UNIT PARTS

For Models: KSRD22FKWH15, KSRD22FKBT15, KSRD22FKSS15, KSRD22FKBL15, KSRD22FKST15

(White)

(Biscuit)

(Black)

(Stainless-VCM)

Illus. No.	Part No.	DESCRIPTION
2	2225834	Fan, Blade
3	2223953	Condenser Assembly
4	489464	Screw
5	2208280	Clip, Wire
6	8281160	Screw
7	489396	Clip
8	2161302	Sleeve
9	2216997	Bracket, Insert
10	2255009	Clip, Retaining
11	2220642	Tube Suction
12	4387731	Cover (Service Compressor Only)
13	2187145	Overload (Service Only)
14	2216914	Clip, Condenser
15	2261599	Tube, Condenser to Heat Loop
16	2188831	Start-Device, Combination (Start Relay and Overload) for Production Compressor Only
17	2255130	Capacitor Production
	1118576	Service
18	2183454	Relay (Service Only)
20	2182057	Unit Cover, Bottom
21	489478	Screw

Illus. No.	Part No.	DESCRIPTION
22	2188822	Evaporator
23	2161324	Clamp
24	2188729	Fan, Motor
25	1105523	Tray, Evaporator
26	2304288	Heat Shield
27		Drier
	2199167	Production
	4387019	Service
28	2255011	Compressor (Includes Items 12, 13, 17, 18, 27, 38 & 39) (Also Order 876765 Tube Kit)
30	2160501	Unit Mounting Frame
32	2181929	Fan, Motor Bracket
33	2188174	Heater, Defrost
34	2304287	Clip
36	2187783	Unit, Harness
37	489373	Screw
38	4387765	Wire, Capacitor (Service Only)
39	1100826	Grommet (4) Production
	4387558	4387558 Service
40	489340	Screw
41	2196202	Air Baffle
42	2155547	Clip, Heat Shield

Illus. No.	Part No.	DESCRIPTION
48	2149718	Unit Mounting Rail
49	8281232	Screw
50	2186496	Guard, Fan
52	2172840	Strap
53	489427	Screw
55	488649	Screw

**Following Parts Not Illustrated  
and Optional Parts Not Included**

978025	Valve, Access (1/4")
978026	Valve, Access (5/16")
978027	Valve, Access (3/8")
978028	Valve, Access (1/2")
978029	Valve, Access (5/8")
978030	Valve, Access (3/4")
876764	Valve, Access (3/16")

## **REFRIGERANT CHARGE**


5.0 oz.  
(R-134A)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# AIR FLOW PARTS


For Models: KSRD22FKWH15, KSRD22FKBT15, KSRD22FKSS15, KSRD22FKBL15, KSRD22FKST15  
 (White) (Biscuit) (Stainless Steel) (Black) (Stainless-VCM)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CONTROL PARTS

For Models: KSRD22FKWH15, KSRD22FKBT15, KSRD22FKSS15, KSRD22FKBL15, KSRD22FKST15  
 (White) (Biscuit) (Stainless Steel) (Black) (Stainless-VCM)




Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	8201785	Control Box	13	489084	Screw (2)	24	489391	Fastener, Push-On
2	2196001	Tube Barrier, Thermostat	14	2179920	Light Bar (RC)	25	2211959	Escutcheon, Control Box
3	489214	Screw (4)	15	2161306	Pivot Arm	26	2179921	Light Bar (FC)
4	2149705	Light Switch	16	489290	Screw (2)	27	2175513	Window
5	2161282	Thermostat	17	2162085	Light Socket	28	2213462	Harness, Indicator Light
6	2303822	Electronic Control	18	2172931	Heat Shield	29	489203	Spring Washer
7	489398	Screw (2)	19	527949	Light Bulb	30	2161307	Connecting Rod (Short)
9	627068	Screw	20	2212237	Control Box Harness	31	489203	Washer
10	2181741	Slide, Air Control	21	1115374	Clip, Wiring	32	2200096	Cover, Light Lens
11	2172906	Grommet, Light Bar	22	1115375	Clip, Wiring			
12	2161466	Slide, Thermostat	23	2161308	Connecting Rod (Long)			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# ICEMAKER PARTS

For Models: KSRD22FKWH15, KSRD22FKBT15, KSRD22FKSS15, KSRD22FKBL15, KSRD22FKST15  
 (White) (Biscuit) (Stainless Steel) (Black) (Stainless-VCM)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# ICEMAKER PARTS

For Models: KSRD22FKWH15, KSRD22FKBT15, KSRD22FKSS15, KSRD22FKBL15, KSRD22FKST15  
(White) (Biscuit) (Stainless Steel) (Black) (Stainless-VCM)

Illus. No.	Part No.	DESCRIPTION
1	489084	Screw
2	2209774	Chute, Water
5	628379	Clip, Fuse
6	488208	Screw
7	2181943	Tube, Water
9	489478	Screw
10	2188708	Valve, Solenoid
16	2208136	Clamp, Tube
18	2174155	Cover
19	488649	Screw
20	628228	Mold & Heater Assembly (Also Order 542638 Silicone Grease)
22	628356	Fill Cup
23	627843	Ejector
24	2182124	Ice Striper
25	2194712	Support
26	627796	Retainer, Thermostat
27	628397	Thermostat (Also Order 542369 Cement Alumilastic)
28	8533917	Screw
30	489276	Screw
31	2209675	Shut Off Arm
33	628320	Bracket
35	626678	Module Assembly (Includes Items 37 & 38)
37	626676	Motor
38	489136	Screw

## OPTIONAL PARTS

For Models: KSRD22FKWH15, KSRD22FKBT15, KSRD22FKSS15, KSRD22FKBL15, KSRD22FKST15  
 (White) (Biscuit) (Stainless Steel) (Black) (Stainless-VCM)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
Parts Not Illustrated and Optional Parts (Not Included)								
<b>Customer Touch-Up Material</b>								
	*350942	Primer, White (12 Oz. Spray Can)		8129	Coil Brush		799340	Enamel, Black (1 Qt. Uncut)
	*350939	Enamel, Black (12 Oz. Spray Can)		212643	Sealer, Gum (4 Feet)		799344	Enamel, White (1 Qt. Uncut)
	*350930	Enamel, White (12 Oz. Spray Can)		479502	Tape, Vinyl (3/4 x 108")		4392900	Enamel, Biscuit (1 Qt. Uncut)
	*4392901	Enamel, Biscuit (12 Oz. Spray Can)		876370	Kit, Insulation (2 Pcs. x 3" x 24" X 48")			
	72017	Brush Touch-Up Kit (White)		876305	Kit, Insulation (14 Pcs. x 3" x 24" x 48")			
	4392899	Brush Touch-Up Kit (Biscuit)		978941	Insulation, Fiberglass (63-1/2" x 35-1/2" X 2-5/8")			
	72032	Brush Touch-up kit (Black)		876029	Kit, Foam Slab (30" x 32-1/2" x 1-1/2")			
<b>Miscellaneous</b>								
				505587	Sealer, Mastic (1 Qt.)			
				503695	Cork, Sealer (1/4 Pound)			
				511873	Touch-Up, White Porcelain (2 Oz.)			
				542638	Grease, Silicone (1/2 Oz.)			
				542639	Cement, Alumilastic (1-1/4 Oz.)			
				606755	Bag, Insulation (36-5/8" x 46")			
				799833	Kit, Evaporator Repair (Aluminum Epoxy)			
				833938	Kit, Terminal Connector			
				2006783	Cleaner, Stainless Steel (2 oz)			
				2209779	Ice Container Assembly			
<b>Refinishing Material</b>								
<b>TORX SCREW WRENCH</b>								
1117510 Torx Key								
*Important: The spray paint is not to be used where the paint may make contact with the door gaskets.								

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST